



bio-METRICA

One Identity, Everywhere.

www.bio-metrica.com · +1-407-209-3373 · tehcnical-sales@bio-metrica.com

Bio-Metrica Voter Registration System - VRS™



Voter Registration System -

VRS™ is a modular system that provides an end-to-end voter registration solution. From securely enrolling and identifying citizens using biometrics, **VRS™** is a scalable from small municipal implementations, to nationwide voter registration systems utilizing stationary and portable identification terminals to ensure citizens are properly so they can cast their vote.

All of this runs on the robust **BII™** architecture, which allows

collected information to be shared across multiple applications.

VRS™ makes it easy to enroll and identify citizens using biometrics to verify their identity and organize that information in an easy to query system. By using biometrics, **VRS™** provides a higher level of security by ensuring people are who they claim to be and are therefore are not counted multiple times ensuring that election results are not skewed by fraudulent voters voting.

VRS™ provides a set of functions that allow easy enrollment and identification of a citizen:

- Enroll multiple types of biometrics via a variety of devices from different manufacturers.
- Take a high quality picture that can be also used to identify a citizen via facial recognition.
- Maintain a strict log of data that has been entered in the system including enrolled citizens, and citizens that have been already identified at particular polls.
- Keep detailed information of administrators performing verification of citizens and controlling access to system data via a multi-tiered access scheme.
- Provide detailed reports and activity logs of system users and administration staff to prevent abuse of the system.
- Flexible deployment on desktops, mobile systems, or hand held terminals for remote deployments.

VRS™ is used by governments and other entities which need a robust, secure system to enroll and identify citizens. **VRS™** is a customizable system which can be adapted for any organization's needs.

Enrollment

The Enrollment screen is where all data on the citizen is entered in the system. The operator will capture all the information in a customizable form and then enroll the user's fingerprints (or other biometric types) and take several photos. Enrollment generally includes both demographic and biometric information including identification characteristics, a picture, name, address and identification documents (by default the system will use fingerprints, but the biometric method can be customized according to customer requirements). Enrollment can be configured in a way that it will not let the operator to save the information until a set of activities are established, such as high resolution fingerprints, minimum number of fingerprints captured, specific mandatory fields, high resolution pictures taken, immediate duplication search within the local database, and near real time duplication search for the entire database, etc.

Identification / Verification

After enrolling the citizen, **VRS™** makes it easy to confirm their identity for when they return to their polling place. **VRS™** uses a variety of methods to identify and verify the identity of a citizen.

There are two types of searches that can be performed.

- **Verification Search (1:1):** An operator can enter biographical information for the user in order to locate the specific record.
- **Identification search (1:N, 2:N, 4:N or 10:N):** This method will take a fingerprint and compare it to all other fingerprints in order to find a matching record. In order to minimize the amount of records the search is required to go through, the operator can also enter some combination of a biographical plus biometric trait.

Out of the two the short list search is the most efficient and utilizes less server resources.

Investigations

While **VRS™** makes it very easy to enroll new citizen, there is always the possibility for people to try and take advantage of a system through the easiest way: Through Operators.

In order to ensure fraudulent data is not in the system, **VRS™** runs has two methods of checking newly entered information is both unique and genuine. Both of these searches are run nightly to check new records crated during the day.

- **Biometric Duplication Search:** This search method takes each of the enrolled biometrics and compares them against all of the previously enrolled records in the database.
- **Biographic Information Search:** The second search takes the biographical information collected during enrollment and performs a comparison against text entered in other records.

In the Investigations area, results from both of these searches are displayed, and combined to allow investigators to remove fraudulent records as well as identify individuals who are perpetuating the fraud.



bio-METRICA
One Identity, Everywhere.

www.bio-metrica.com · +1-407-209-3373 · tehnical-sales@bio-metrica.com